





NOTES:

1. WOOD NAILER MUST EXTEND PAST TOTAL WIDTH OF METAL FASCIA DECK FLANGE.
2. TO REMOVE FINISHING OILS, SCRUB METAL FLANGE WITH PVC & KEE HP MEMBRANE CLEANER; ALLOW TO DRY PRIOR TO APPLYING PRIMER.
3. WHEN METAL FASCIA BY OTHERS IS USED, FASTENER TYPE AND FASTENING FREQUENCY SHALL BE RECOMMENDED BY METAL EDGE MANUFACTURER.

	—• PVC MEMBRANE	PRESSURE-SENSITIVE PVC COVER STRIP		DETAIL NO.
	—• APPROVED SUBSTRATE			U-1G
	—• SEE NOTE(S)	For additional information, refer to Specifications	THERMOPLASTIC PVC	