

# CARLISLE'S X-TENDA COAT™ GENERAL PURPOSE CLEANER



## Overview

X-Tenda Coat™ General Purpose Cleaner is a single-component, 100% biodegradable water-based cleaner. It was specifically developed for cleaning TPO, PVC, Hypalon, metal, smooth BUR and APP or SBS modified bitumen surfaces. It can also be used to clean existing acrylic or Hypalon coatings, concrete deck surfaces and masonry wall surfaces. X-Tenda Coat General Purpose Cleaner is a low-viscosity, light yellow liquid that removes dirt, chalking, and other contaminants, leaving a clean surface for the application of Carlisle's X-Tenda Coat coating.

## Surface Preparation

Remove heavy deposits of dirt, leaves, pine needles and other debris using a broom or air blower. Remove any rocks, branches, or other large foreign objects. X-Tenda Coat General Purpose Cleaner can be applied directly over surfaces containing residual amounts of dirt, dust and other contamination.

## Mixing

Dilute at a 1 to 10 ratio with clean water. For example, 5 gallons of General Purpose Cleaner should be mixed with 50 gallons of water in a 55-gallon drum.

## Coverage Rate

1 gallon per 150 to 200 square feet in diluted form

## Application

1. Safety glasses with side shields and latex gloves are recommended when transferring X-Tenda Coat General Purpose Cleaner from the shipping container to the sprayer.

2. For best results, dilute X-Tenda Coat General Purpose Cleaner at a 1 to 10 ratio. It can be applied using a Hudson-type agricultural sprayer, or other, low-pressure equipment. If using a Hudson sprayer, adjust spray nozzle to achieve a uniform spray pattern with a 3- to 4-foot arc. For higher output, use a sprayer rated at one gallon per minute with a 615 to 619 size tip.
3. Apply using a coverage rate of 150 to 200 square feet per gallon of diluted solution. This gives a yield of 16.5 to 22 squares per gallon of concentrate.
4. Allow X-Tenda Coat General Purpose Cleaner to stand a minimum of 15 minutes penetrate and lift the surface dirt. Rinse with clean water using a minimum 2,000-psi pressure washer.
5. Begin the power-rinse at the lowest point on the roof and work upwards, keeping the pressure washer tip within 12" of the surface. Once the highest point on the roof is reached, work down again with a second rinse.
6. Repeat rinsing until all X-Tenda Coat General Purpose Cleaner is removed.
7. Areas with heavy dirt accumulation may require a second application and/or scrubbing with a stiff bristle broom.
8. Allow surfaces to dry thoroughly prior to application of the X-Tenda Coat coating.

## Packaging

X-Tenda Coat General Purpose Cleaner is available in 1-gallon plastic bottles (4 per case) or 5-gallon pails.

## Precautions

1. Review the applicable Material Safety Data Sheet for complete safety information prior to use
2. DO NOT ALLOW TO FREEZE. Do not store sealed containers in prolonged sunlight
3. Do not apply at temperatures below 40°F (4°C)

## Environmental/Regulatory Information

When used as directed, X-Tenda Coat General Purpose Cleaner will not harm ground vegetation, water collection ponds, or water treatment plants. Accidental ingestion by wildlife should cause no harmful side effects. It meets all applicable U.S.D.A., FDA, and OSHA requirements.

### LEED® Info

Post-industrial Recycled Content	0%
VOC Content	0
Manufacturing Location(s)	Olympia, WA