

1

6" (152mm)

FASTEN MEMBRANE AND FLASH CURB OR WALL WITH CURED EPDM MEMBRANE FOLLOWING STANDARD PROCEDURES USING BONDING ADHESIVE AND SecurTAPE AT MEMBRANE SPLICE.

2

CENTER FOLD LINE

PRESSURE-SENSITIVE ELASTOFORM FLASHING 6"X6" (152X152mm)

USE PRE-CUT T-JOINT COVERS OR CUT A 6"X6" (152X152mm) & 12"X12" (305X305mm) SECTION OF PRESSURE-SENSITIVE ELASTOFORM FLASHING AND ROUND CORNERS

3

SURE SEAL PRIMER

CLEAN THE DRY SPLICE AREA OF THE EPDM WITH EPDM PRIMER; APPLY LAP SEALANT 1/2" (13mm) MIN. FROM THE CURB AS SHOWN IN STEP 4.

4

POLY FILM

REMOVE & REPLACE POLY BACKING ON FLASHING. FOLD 6"X6" FLASHING IN HALF WITH ROUNDED PORTION TURNED UP. CENTER ON CORNER & FIRMLY PRESS AGAINST VERTICAL SURFACE

5

ROLL & CREASE FLASHING TIGHTLY INTO ANGLE CHANGE & FIRMLY ROLL FLASHING ONTO THE DECK MEMBRANE

USE HEAT GUN TO WARM THE FLASHING IN COLD WEATHER

6

AFTER ADHERING, ROLL WITH A TWO INCH WIDE STEEL HAND ROLLER. PAY PARTICULAR ATTENTION TO THE STEP OFFS AND ANGLE CHANGES

7

ROLL STEP OFFS AND ANGLE CHANGES

8

CLEAN THE SPLICE AREA WITH EPDM PRIMER. INSTALL THE 12"X12" SECTION OF PRESSURE-SENSITIVE ELASTOFORM FLASHING TO EXTEND A MINIMUM 2" BEYOND THE PREVIOUSLY APPLIED 6"X6" FLASHING (STEPS 4-6).

9

SEAL ALL EDGES WITH LAP SEALANT AS SHOWN

—• EPDM  
 —• APPROVED SUBSTRATE  
 0 —• SEE NOTE(S)

OUTSIDE CORNER FLASHING FOR PROJECTS WITH 90-MIL MEMBRANE OR 25 & 30-YEAR WARRANTIES

For additional information, refer to Specifications

DETAIL NO.  
 U-15H  
 THERMOSET UNIVERSAL